## Uniaxial Loading





# ENGINEERING MATERIAL PROPERTIES

#### NORMAL STRESS


$$\sigma = \frac{P}{A}$$

#### NORMAL STRAIN

$$\epsilon = \frac{\delta}{L}$$

#### STRESS VS. STRAIN

SOFT ALLOY



NOTE: NOT TO SCALE

"ut tensio, sic vis"

-Robert Hooke, 1678

#### HOOKE'S LAW

$$\sigma = E\epsilon$$

CONSTITUTIVE RELATION

DERIVED FROM STRESS-STRAIN PLOT

#### YOUNG'S MODULUS

E	 $\sigma$
Ľ	 $\epsilon$

material	Young's modulus (10 <sup>9</sup> N/m <sup>2</sup> )	
structural steel	200	
aluminum	70	
glass	65	
high-strength concrete	30	
Douglas Fir	13	
Polystyrene	3	





Fig. 2.16 Stress-strain diagrams for iron and different grades of steel.


#### STRESS VS. STRAIN

LOW-CARBON STEEL




NOTE: NOT TO SCALE

#### PLASTIC DEFORMATION




NOTE: NOT TO SCALE

#### DUCTILITY



$$ductility = \frac{A_o - A_f}{A_o}$$






#### ULTIMATE TENSILE STRENGTHS


MATERIAL	TENSION (MPA)	COMPRESSION (MPA)
STRUCTURAL STEEL ASTM-A36	400	~400
4.5%C CAST IRON ASTM-A48	170	655
Douglas Fir	100	50
CONCRETE	SMALL, VARIABLE	40
MARBLE	20	240


#### CONCRETE






#### ANISOTROPIC MATERIALS






### EXPERIMENTAL SETUP

#### TENSION TESTING






#### INSIDE A LOAD CELL



#### STRAIN GAUGES






# HARDNESS TESTING RESISTANCE TO DEFORMATION

#### ROCKWELL HARDNESS TESTING

Depth to which indenter is forced by minor load



Depth to which indenter is forced by major load

Increment in depth due to increment in load is the linear measurement that forms the basis of Rockwell hardness tester readings



#### INDENTERS



#### COMMON ROCKWELL SCALES

SCALE	MATERIALS	INDENTER	MAJOR LOAD
В	S O F T M E T A L S	HARDENED STEEL BALL	100 KGF
C	HARD METALS	BRALE	150 KGF